







Mast & Floodlights spare parts



LED 100W floodlight



24Vdc power supply



Floodlight support



Anti-drag spacer



Multiposition handle





Coiled cable



Hydraulic cylinder



Angular runner



Angular runner reinforcement



Mast rope L.1310 mm full / dug eyelet



Mast rope L.1290 mm full / dug eyelet



Lights tilting Sensor



Pulley D.58

Pulley D.62

Pulley D.60

Pulley D.63









Electrical spare parts



Solar panel



Solar panel protection



Solar panel charge regulator



DSE3110 controller



Fuel level gauge



Battery charger gauge



RCBO 13A



Lamp switch



Light sensor



Timer



10 modules cover



2 poles switch



Mast control buttons



Green signal lamp



Light sensor capacitor



Battery charger socket



Emergency stop button



12V 30A relay



12V 70A relay



Mains inlet 230V 16A







info contacts

**** + 39 02 942 1724

info@trime.it

www.trime.it

Electrical spare parts



Junction box



Earth post



Engine battery



AGM battery



Battery connector



Contactor switch



Battery charger



Power contactor



Tilting selector

Engine spare parts



Battery charger regulator



Fuel filter





Air filter



Oil drain pipe kit



Fuel lift pump



Fuel pre-filter









Hydraulic unit spare parts



Hydraulic tank cap



Electrovalve solenoid body



Electrovalve energizing coil



Electrovalve energizing coil plug



250Bar valve

Chassis spare parts



Handle with lock



Door hinge



Fuel sender unit



Stabilizer locking pin



Knob









Lighting Tower Specialist

TRIME s.p.a.

Strada per Robecco, snc

20081 Cassinetta di Lugagnano (MI) - ITALY

Tel. +39 02 942 1724

www.trime.it - info@trime.it